



Installing heavy duty cleat on Wave Dock, Part #21929

1. Align cleat with the threaded inserts on the Wave Dock section.



2. Attach the cleat with the $\frac{1}{4}$ x 2" screws. Be sure to tighten securely.

