



21952 and 21954 Attaching Dock Post Attachments and 2" or 4" Bushing to Wave Dock

2" Schedule 40 pipe or other pipe with a 2-3/8" outer diameter is recommended for use with the Wave Dock. For 4-6" pilings, use the post attachment without the pipe adapter.

1. Using your dock layout plan, determine where posts will be located. It is recommended to place a post every 15–20 ft on each side of the dock and on the inside and outside corners of L-shapes.
2. Slide a post attachment into a side channel of a dock section to the desired location, making sure to line up one of the threaded inserts with a hole in the decking (although there are two holes in the post attachment, you only need to use one). Use silicone spray to help the attachment slide easier if necessary.
3. Insert a 3/8 x 1 1/2" bolt and washer through the decking into the threaded insert of the post attachment and tighten.
4. Insert a 2" or 4" bushing into the post attachment, lining up the holes with the threaded inserts in the post attachment.
5. Insert 3 bolts (3/8 x 1 1/4") and 3/8" washers through the holes of the bushing and into the threaded inserts in the post attachment and tighten.



Dock Post attachment slid into H-channel on dock section





Completed installation of 2" Bushing