



Assemble Wave Port with Sea Wall Attachment Kit – Part 22996



Parts included in kit



Completed Sea Wall Attachment Kit

1. Tip Wave Port up on its side and attach one c-clamp with three $\frac{3}{8} \times 1 \frac{1}{2}$ " bolts by lining up the holes in the c-clamp with the threaded inserts in the bottom of the Wave Port. Repeat on the other side



2. Attach hinge piece by sliding it in from the end of the channel. Secure with a 3/8 x 1 1/2" bolt using the top hole in the Wave Port and lining it up with the threaded insert in the hinge piece.



3. Sea wall brackets can now be attached to the hinge piece. It may be easier to attach the galvanized brackets to the sea wall first and then attach the Wave Port. Attach the brackets to the Port using the 1/2" x 7" galvanized bolts, washers and nuts. Use two nuts on each bolt and tighten them against each other to prevent them from loosening and coming off.

