

Installing the 2" and 4" Bushings in the Stand-alone Port, Items 22952 and 22954

The 2" bushing fits 2" pipe which has an outside diameter of 2 3/8" The 4" bushing fits 4" PVC pipe which has an outside diameter of 4 $\frac{1}{2}$ "

1. At the front of the Stand-alone Port insert the bushing into the anchoring hole. Line up the three holes in the bushing with the threaded inserts in the Port. Secure with the $3/8 \times 1 \frac{1}{4}$ bolts and washers. Repeat on the other side.







