

TRITON Customer Instruction Sheet

KIT NO.:
13733

DESCRIPTION	REV 0	DRAWN BY: L Wagner	DRAWING NO.:
WIRELESS WINCH CONTROL		DATE: 4-1-09	13732

Parts List

ITEM	PART NU	DESCRIPTION	QTY
1	13731	WIRELESS CONTROL, WINCH	1
2	08738	SCREW, TEK #14 x 1 1/4	2
3	06696	SCREW, TEK #12	2
4	09589	WASHER, FLAT 1/4 NYLON	4

INSTALLATION INSTRUCTIONS:  READ COMPLETELY BEFORE STARTING!

- 1) FOLLOW WIRING INSTRUCTIONS THAT CAME WITH THE WARN WIRELESS CONTROL SYSTEM.
- 2) FASTEN REMOTE RECEIVER TO TRAILER USING SELF DRILLING SCREWS #2. ATTACH THRU FRONT DECK PROTECTOR. NOTE: MOUNT CLOSE ENOUGH TO WINCH TO ATTACH BOTH ENDS OF THE WIRE HARNESS.
- 3) SEPERATE REMOTE HOLSTER HANDLEBAR MOUNT HALVES. USE MOUNT HALF THAT DOES NOT HAVE BRASS THREADED INSERTS TO MARK HOLE LOCATION ON OUTSIDE OF STORAGE BOX AND PRE-DRILL MOUNT HOLES USING A 5/32 DRILL. ATTACH WIRELESS REMOTE HOLSTER BRACKET TO INSIDE OF STORAGE BOX USING SELF DRILLING SCREWS #3 AND NYLON WASHERS #4. NOTE: DO NOT OVER-TIGHTEN SCREWS AS THIS CAN STRIP OUT PLASTIC MOUNT.
- 4) ATTACH HOLSTER TO MOUNT BRACKET USING SCREW PROVIDED WITH WARN WIRELESS CONTROL SYSTEM.