

INSTALLATION INSTRUCTIONS

NOTE - LEAVE ALL HARDWARE LOOSE UNTIL INSTRUCTED TO TIGHTEN.

1. ATTACH TWO 12953 - BRACKET, STAKE POCKETS TO EACH SIDE PANEL WELDMENT WITH 1/4" HARDWARE. SEE DETAIL -A-
2. USING CARRIAGE BOLT SLOT ATTACH BRACKET TO SIDERAIL OF TRAILER WITH 3/8" HARDWARE.
3. SLIP FRONT PANEL INTO STAKE POCKETS AND ATTACH TO SIDE PANELS WITH 1/4" HARDWARE & CORNER JOINER. SEE DETAIL -B- & -C-
4. DRILL 5/16" HOLE IN FRONT STAKE POCKET 1/2" FROM TOP OF POCKET AND 3/4" FROM FRONT OF POCKET ON THE SIDE WHERE THE 1/4" HARDWARE IS TO BE ATTACHED. ATTACH FRONT PANEL TO STAKE POCKETS WITH 1/4" HARDWARE. SEE DETAIL -D-
5. TIGHTEN ALL HARDWARE.
6. USING THE SIDE STAKE POCKETS AS A TEMPLATE DRILL 13/32" HOLE THRU SIDE RAIL FOR THE TOP MOUNTING HOLES. ATTACH 3/8" HARDWARE
7. INSTALL THREE 07600 - SCREWS THRU HOLES IN BOTTOM OF FRONT PANEL AND INTO TRAILER FRAME.

TRITON Customer Instruction Sheet

KIT NO.
12300 - 1082
12310 - 1282

DESCRIPTION

REV 1

DATE

12-11-07

DRAWING NO.

AUT SOLID SIDES HD

DRAWN BY

L Wagner

12360

Parts List

ITEM	PART NU	DESCRIPTION	QTY
1	12357	WELDMENT, SOLID FRONT 82W	1
2	12356	WELDMENT, SOLID SIDE RH 12L	1
2	12276	WELDMENT, SOLID SIDE RH 10L	1
3	12355	WELDMENT, SOLID SIDE LH 12L	1
3	12275	WELDMENT, SOLID SIDE LH 10L	1
4	11389	JOINER, CORNER x 1 1/32	2
5	12953	BRACKET, STAKE POCKET	4
6	04751	BOLT, HHCS 1/4-20 X 3/4 Y/Z	8
7	09571	BOLT, HHCS 1/4-20 X 1 Y/Z	4
8	07771	BOLT, HHCS 1/4-20 X 2 Y/Z	10
9	03671	NUT, HEX 1/4-20 LOC Y/Z	22
10	03418	WASHER, FLAT 1/4 Y/Z	44
11	02906	BOLT, CARRIAGE 3/8-16 X 1 Z/Y	8
12	00982	BOLT, HHCS 3/8-16 x 1 1/4 Y/Z	8
13	01153	NUT, HEX 3/8-16 LOC Y/Z	16
14	06105	WASHER, FLAT 3/8 SAE Y/Z	24
15	07600	SCREW, TEK #10 X 13/16	3

