

INSTALLATION INSTRUCTIONS: READ COMPLETELY BEFORE STARTING!

- 1) SET GAS TRAY #7 ACROSS SIDE RAILS AND TONGUE OF TRAILER. CENTER TRAY WITH TRAILER FRAME.
- 2) USING HOLES IN TRAY AS A TEMPLATE, DRILL TWO 1/4" HOLES THRU BACK OF CARGO BOX. ATTACH TRAY TO CARGO BOX USING HARDWARE SHOWN.
- 3) SCREW TRAY TO TOP OF TRAILER FRAME USING 3 SELF DRILLING SCREWS #2. NOTE: BE SURE TO SCREW THRU CENTER OF SIDE RAILS AND TONGUE.
- 4) SET GAS BOTTLE ONTO TRAY TO GET HEIGHT FOR RETAINING ROD. AFTER DETERMINING PROPER HEIGHT, REMOVE GAS BOTTLE AND POSITION BRACKETS #9 SO THAT OUTER EDGE OF BRACKET IS FLUSH WITH EDGE OF BOX. USING BRACKET AS A TEMPLATE, DRILL THRU BACK OF CARGO BOX USING 1/4" DRILL AND FASTEN BRACKETS #9 USING HARDWARE SHOWN.
- 5) PLACE GAS BOTTLES ON TRAY AND SLIP RETAINING ROD THRU BRACKETS AND BOTTLE HANDLES. INSTALL LYNCH PIN #1 THRU HOLE IN END OF RETAINING ROD.

TRITON Customer Instruction Sheet

KIT NO.

12410

DESCRIPTION

GAS TRAY

REV 0

DATE

8-30-06

DRAWN BY
L Wagner

DRAWING NO.

12398

Parts List

ITEM	PART N	DESCRIPTION	QTY
1	06034	PIN, LYNCH 3/16	1
2	06696	SCREW, TEK #12	3
3	06182	BOLT, HHCS 1/4-20 X 3/4 SS	2
4	05513	NUT, HEX 1/4-20 LOC SS	6
5	08130	WASHER, FENDER 1/4 X 1 1/2	6
6	09977	BOLT, CARRIAGE 1/4-20 X 3/4 SS	4
7	10684	TRAY, GAS BOTTLE-PAINTED	1
8	10682	ROD, RETAINING	1
9	10683	BRACKET, GAS TRAY-ZINC	2

