



411 West Congress St., Maple Lake, MN 55358 Toll Free 877-466-8837 [www.wavearmor.net](http://www.wavearmor.net)

## Dock Post Axle Adapter Instructions

**Tools required:**  $\frac{3}{4}$ " wrench or socket and ratchet

Item	Description	Qty
1.	Welded axle adapter	2
2.	$\frac{1}{2}$ " x $1\frac{1}{2}$ " bolt	4
3.	Dock wheel (not included)	2
4.	Dock post (not included)	2
5.	Dock axle (not included)	1

Use a pipe with an outside diameter of  $1\frac{7}{8}$ " for the axle  
(this is the diameter for what is called  $1\frac{1}{2}$ " pipe).

### Assembly instructions:

1. Slide the axle adapter onto the dock post on one side.  
Repeat for the other side.
2. Slide the axle through both of the axle adapters. Center the axle, allowing enough room on each end for the dock wheel. Tighten the bolts that hold the axle in place.
3. Install the dock wheels.
4. Raise the dock post until it is even with the bottom of the adapter and then tighten the bolt that holds it in place. Repeat for the other side.

